Wireless Camera Detector (630-1151)
Product Details

Specifications:

- Model: P7030
- Battery: Two CR2032
  (RadioShack catalog number 23-162)
- Frequency Range: 50MHz - 3GHz
- Weight: 1 oz.
- Dimensions: 3.25" x 1.25" x .75"

The easy to use Camera Detector is so small it can be carried or stored anywhere. Discreet sweeps of the home, office or hotel room can be done quickly and efficiently. When a wireless camera is discovered, a LED light flickers and an audible alarm sounds. An adjustable sensitivity tuner allows you to scan variable distances and can check multiple channels. It can detect frequencies anywhere from 50MHz to 3GHz, picking up most wireless cameras. Advanced circuitry eliminates background noise, minimizing false alarms.

How to Operate:

1. Slide and remove battery lid. Install two CR2032 batteries matching (+) and (-) poles as shown (shows positive side up on both batteries). Slide lid back into place.
2. Switch unit on. Green light should appear on LED. IF LED lights red, remove and replace batteries.
3. When a wireless camera is discovered, LED will flash green and audio alarm will sound.

Notes:

- Do no bend or attach key chains or other items to unit.
- This unit detects radio signals from wireless cameras only. It cannot detect the presence of CCTV cameras or microphones.
- Remove batteries when unit will not be used for extended periods of time.
- Avoid placing unit in extreme temperatures. Do not get wet or drop.